



# INSTALLATION & OPERATING INSTRUCTIONS

## Cold Water Start & Cold Water Run



**For Hi Delta, MVB & Raytherm  
Heaters & Boilers**

This manual should be maintained in legible condition and kept adjacent to the heater or in another safe place for future reference.

**Raypak®**  
A Rheem® Company

**Rev. 10** reflects the following:

**Changes to:** None

**Additions:** None

**Deletions:** Illustrated Parts List (was on previous pages 34-39)

---

# CONTENTS

<b>WARNINGS</b>	<b>4</b>	Connecting Cold Water Start to Multi-Heater Interlock Box	18
<b>GENERAL SAFETY</b>	<b>5</b>	Connecting Heater to Cold Water Start Multi-Heater Interlock	18
Time/Temperature Relationships in Scalds	5	Actuator to Valve Orientation	19
<b>COLD WATER START</b>	<b>6</b>	Three-Way Valve Ball Orientation	19
Installation	6	Valve Installation	19
Check Power Source	6	4 Inch Valve Orientation	20
Mounting the Control Box	6	Connecting the Actuator	20
Installing the Temperature Sensor	7	Typical Cold Water Start Multiple Boiler Piping	21
Connecting the Valve Assembly	7	Wiring Diagram	22
Connecting Power to the Controller	8	<b>COLD WATER RUN</b>	<b>23</b>
Connecting Boiler to Cold Water Start Operation	8	Purpose	23
Operation	8	Typical Cold Water Run Applications	23
Cold Start Sequence of Operation	9	CWR vs. CWS	23
Troubleshooting	10	Installation	23
Mounting the Actuator to the Valve	11	Installation Codes	23
Mounting Brackets	11	Mounting the Control Box	23
Locating the Rotation Stop	11	Injector & Heater Pump Comparison	24
Drive Linkage	12	Check the Power Source	25
Verifying Ball Position	12	Injector Pump Wiring	25
Actuator to Valve Orientation	12	Injection Pump Cover Installation	27
Installing the Three-Way Valve	13	Typical Cold Water Run Piping - Heating Applications	29
High Pressure Tab	13	Typical Cold Water Run Piping - Pool Applications	29
Actuator	13	Operation	30
Cold Water Start Troubleshooting Guide	14	Cold Run Sequence of Operation	30
Typical Cold Water Start Piping	15	Cold Water Run Troubleshooting Guide	31
Wiring Diagram	16	Wiring Diagrams	32
Heater Interface Wiring	17	<b>REPLACEMENT PARTS</b>	<b>34</b>
<b>CWS—MULTIPLE BOILER</b>	<b>18</b>		
Materials Included	18		
Installation	18		
Mounting the Control Boxes	18		
Installing the Temperature Sensor	18		
Installing the Three-Way Valve	18		
Connecting Power to the Controller	18		

# WARNINGS

## Pay Attention to These Terms

<b>DANGER:</b>	Indicates the presence of immediate hazards which will cause severe personal injury, death or substantial property damage if ignored.
<b>WARNING:</b>	Indicates the presence of hazards or unsafe practices which could cause severe personal injury, death or substantial property damage if ignored.
<b>CAUTION:</b>	Indicates the presence of hazards or unsafe practices which could cause minor personal injury or product or property damage if ignored.
<b>NOTE:</b>	Indicates special instructions on installation, operation, or maintenance which are important but not related to personal injury hazards.

**NOTE:** Minimum 18 AWG, 105°C, stranded wire must be used for all low voltage (less than 30 volts) external connections to the unit. Solid conductors should not be used because they can cause excessive tension on contact points. Install conduit as appropriate. All high voltage wires must be the same size (105°C, stranded wire) as the ones on the unit or larger.

**NOTE:** Piping diagrams in this manual are not intended to replace an engineered piping system.

**NOTE:** Consult the factory for units with a 30 pound pressure relief valve (PRV).

# GENERAL SAFETY

To meet commercial hot water use needs, the high limit safety control on this water heater is adjustable up to 210°F. However, water temperatures over 125°F can cause instant severe burns or death from scalds. When supplying general purpose hot water, the recommended initial setting for the temperature control is 125°F.

Safety and energy conservation are factors to be considered when setting the water temperature on the thermostat. The most energy-efficient operation will result when the temperature setting is the lowest that satisfies the needs of the application.


Water temperature over 125°F can cause instant severe burns or death from scalds. Children, disabled and elderly are at highest risk of being scalded.

- Feel water before bathing or showering.
- Temperature limiting valves are available.

**NOTE:** When this water heater is supplying general purpose hot water for use by individuals, a thermostatically controlled mixing valve for reducing point of use water temperature is recommended to reduce the risk of scald injury. Contact a licensed plumber or the local plumbing authority for further information.

Maximum water temperatures occur just after the heater's burner(s) have shut off. To determine the water temperature being delivered, turn on a hot water faucet and place a thermometer in the hot water stream and read the thermometer.


DANGER



**Water temperature over 125°F can cause instant severe burns or death from scalds.**

**Children, disabled, and elderly are at highest risk of being scalded.**

**See instruction manual before setting temperature at water heater.**

**Feel water before bathing or showering.**

**Temperature limiting valves are available, see manual.**

## Time/Temperature Relationships in Scalds

The following chart details the relationship of water temperature and time with regard to scald injury and may be used as a guide in determining the safest water temperature for your applications.

Water Temp.	Time to Produce Serious Burn
120°F	More than 5 minutes
125°F	1-1/2 to 2 minutes
130°F	About 30 seconds
135°F	About 10 seconds
140°F	Less than 5 seconds
145°F	Less than 3 seconds
150°F	About 1-1/2 seconds
155°F	About 1 second

Table courtesy of The Shriners Burn Institute

**Table A: Time to Produce Serious Burn**

# COLD WATER START

Before beginning the installation, it's important to first inspect the system and determine what materials you will need. Some parts are included with the controller while others you will need to provide.

- 1 Control Box
- 1 Temperature Sensor
- 1 Valve assembly with actuator (Shipped separately)
- Wiring and mounting hardware (Provided by installer)

**NOTE:** After testing at the factory it may be prudent to ship the piping assembly disassembled and attached to the heater pallet. This is done to avoid shipping damage and it must be reassembled on the jobsite. Use Fig. 1 to assist in reassembling the piping.




Fig. 1: Cold Water Start Assembly

## Installation

### Check the Power Source

**CAUTION:** Do not use for swimming pool applications

**WARNING:** Using a multi-meter, check the following voltages at the breaker panel prior to connecting any equipment. Make sure proper polarity is followed and house ground is proven.




Fig. 2: Wiring Connections

Check the power source:

- AC = 108 VAC Minimum, 132 VAC MAX
- AB = 108 VAC Minimum, 132 VAC MAX
- BC = <1 VAC Maximum

## Mounting the Control Box

The control box should be mounted on the side of the heater to which the system piping and valve assembly are to be attached as shown in Figs. 4–8. The controller should be mounted so as to provide maximum support by using the mounting holes provided on the base of the controller to the side center brace on the heater. On MVB and Hi Delta models, locating dimples are provided for ease of drilling the mounting holes. You will need to drill mounting holes through the heater side panel for the routing of wiring and the sensor.




Fig. 3: Multi-meter

## Installing the Temperature Sensor

Avoid routing wiring on or near other electrical wires, conduit, motors, spark igniters or other sources of high intermittent voltage or current. The sensor should be placed in the dry well on the inlet header, or as indicated in the piping for multiple heaters, as shown on page 21. Ensure it is installed using thermal paste (field supplied) and that it is held firmly at the bottom of the well.

## Connecting the Valve Assembly

Connect the valve assembly into the bypass piping. The branch (port B) is connected to the crossover pipe (bypass between inlet and outlet). The actuator tail stock should be oriented to point down. Refer to the Actuator to Valve Orientation section.

Route wiring from the valve to the controller thru one of the bottom panel conduit knockouts to TB2. Refer to the wiring diagram provided on the inside of the controller cover assembly.

**CAUTION:** Miswiring the actuator may cause unwarrantable damage. Verify the wire colors against the actuator make and model.




Fig. 4: Component Locations—Hi Delta

**NOTE:** Four knockouts are located on the bottom of the control for ease of installation.




Fig. 5: Component Locations—Raytherm Models 514-824




Fig. 6: Component Locations—Raytherm Models 926-1826




Fig. 7: Component Locations—Raytherm Models 2100–4001





Fig. 8: Component Locations—MVB

**CAUTION:** Install the foil-faced insulation on the inside of the rear panel of MVB heaters as indicated in Fig. 8. Use spray adhesive or high temp foil tape to attach the insulation. Ensure that the foil faces the heat exchanger assembly. Failure to install this insulation as directed can cause overheating of the components and may void the warranty on the control.



\*The reset switch may be located on the front control panel on some MVB models.

Fig. 9: Location of TB1 in Control Box

## Connecting Power to the Controller

Connect power from the 120 VAC power input of the heater to the controller power inputs Terminal Block (TB1). This is accomplished by connecting wiring from the control box to the heater 120 VAC power input connections. Refer to the heater wiring diagrams.

## Connecting Boiler to Cold Water Start

The installer must provide five 18AWG stranded wires between the heater and the controller terminal block. Wiring is to be run in separate conduit from line voltage to ensure proper operation. Refer to the diagrams on page 17 for connection points depending on the Raypak product being used.

## Operation

Verify the following upon a CALL FOR HEAT signal from the heater:

1. CALL FOR HEAT: LED on PCB illuminates GREEN.
2. START UP MODE: LED on PCB illuminates YELLOW. It should go out in less than 7 minutes, as the boiler inlet temperature approaches the setpoint temperature.
3. The "ACTUATOR" should be in the fully open position or move to the fully open position if not already there. (Actuator and ball rotated to the at-rest CCW position).



The DIP switches on the three-way valve actuator must be set as indicated in the Fig. 11 below:




Fig. 11: Set Dip Switch Settings — Delta Actuator




Fig. 12: Delta Actuator — Actuator Shown in Full System Flow Position

**CAUTION:** Delta actuator requires the use of the factory-supplied weatherproof cover for outdoor installations.




Fig. 13: Elodrive Actuator — Rotation Knob Setting  
Set adjustment knob to Position 4




Fig. 14: Elodrive Actuator — Actuator Shown in Full System Flow Position

**NOTE:** The Elodrive actuator is NEMA 4 rated. No outdoor cover is required.

## Troubleshooting

Check your power source using a Volt-Ohm meter; check the following voltages at TB1 terminal block:

TB1-1 to TB1-2 = 108 VAC Minimum, 132 VAC Maximum

TB1-1 to TB1-3 = 108 VAC Minimum, 132 VAC Maximum

TB1-2 to TB1-3 = Must be less than .6 VAC

IF CALL FOR HEAT LED does not illuminate when the heater has a CFH signal, check for 24VAC between pins 4 and 5 of TB3 on the cold start control. If voltage is present, check wiring using the wiring diagram. If voltage is not present, the problem exists in the heater.

IF VALVE DOES NOT MOVE: Check for voltage out at TB2-1: Should be a 1VDC to 10VDC output to the actuator valve. If no voltage is present, check for voltage at pin FS on the control board, there should be a 12VDC signal. If the 12VDC signal is not present, verify that the converter is wired correctly using the wiring diagram.

IF INLET TEMP ERROR is illuminated: The setpoint temperature has not been reached within the 7 minute time period.

- Push the Reset Switch (see Fig. 9) or remove power and watch for proper operation.

- Check pump sizing and valve/piping sizing and correct as necessary.

IF SENSOR OUT OF RANGE LED is illuminated: The sensor may have a short or open circuit.

- Press and release the Reset Switch (see Fig. 9) and watch for proper operation.
- Replace sensor.
- Check wiring using wiring diagram.

## Mounting the Actuator to the Valve

When mounting the actuator to the valve, ensure that the valve stem is oriented with the machined flat notch positioned parallel to the “A” and “AB” ports as shown in Fig. 15.

All actuators used by Raypak include the “spring return” safety feature. This means that upon loss of power during operation the valve automatically rotates back to the full system flow position avoiding high limit lockouts or other issues.




Fig. 15: Orient Notch Parallel with “A” and “AB” Ports

## Mounting Brackets (Elodrive)

There are different actuator mounting brackets on the three-way valves. When ordering a replacement bracket you will receive the newest design available from the manufacturer. If it appears to be different than the damaged bracket, the new and old are interchangeable and will fit all valve bodies. See Fig. 16.



Fig. 16: Elodrive Mounting Bracket

## Locating the Rotation Stop (Elodrive)

An internal rotation stop device is built into the actuator mounting bracket and this can be installed only two ways for proper operation of the valve. The stop is labeled on each side with either “D” or “P”. This indicates that the valve is set up for either a diverting application or proportional (mixing) application. Raypak uses the three-way valve in a mixing application therefore the “P” designator must be facing away from the bracket.

The valve rotates in a clockwise direction when it is operating. The rotational stop must be positioned so that the drive linkage can rotate. The drive linkage is keyed to allow only 90 degrees of rotation. Ensure that the key is positioned so the linkage may rotate clockwise as shown in Fig. 17.




Fig. 17: Elodrive Rotational Stop Positioning

### Drive Linkage (Elodrive)

The drive linkage for the 2" NPT and 2-1/2" NPT three-way valves originally were supplied with an orientation groove in the end of the stem. This groove has now been removed by the vendor. All new linkage stems will have a smooth end. Using the groove to determine ball position inside of the valve is not reliable and should be avoided.

### Verifying Ball Position

All field-installed valves must have the ball properly positioned. Occasionally differences occur from the manufacturer of the valve body. The square stem that the drive linkage attaches to should have a machined notch to verify ball position, however on occasion it is not there. To properly orient the ball follow these instructions **PRIOR** to installation into your plumbing system.

- Remove the actuator and base from the valve body.
- With port "AB" facing you, rotate the valve stem approximately 45 degrees clockwise. You must see two port openings if the ball is correctly oriented.

- If you do not see two openings at this point, continue rotating the stem and ball until you do.
- Once you can see two openings, **STOP**, as shown in Fig. 18. Then rotate the stem counterclockwise until only one opening remains e.g. you can see completely through the valve (through ports A and AB).

Now the ball is correctly oriented inside of the valve body. Reassemble the valve, base and actuator, and then install the assembly into your piping system as indicated in this manual.



Fig. 18: Verifying Ball Position

### Actuator to Valve Orientation

Install the actuator so that the tail is pointing downward as shown in Fig. 19. You may also install it horizontally, however, **DO NOT** mount it so that the tail is pointing up as shown in Fig. 20. Doing so will allow water and debris to collect in the cup where the wiring exits the actuator, potentially causing damage.



Fig. 19: Recommended Orientation of Actuator



Fig. 20: Incorrect Orientation of Actuator

## Installing the Three-Way Valve

When threading any pipe into the ports of the three-way valve, a backing wrench **MUST** be employed. You must capture the valve body with a secondary wrench to avoid damaging the internal seals. Valve bodies leaking from improper installation are non-warrantable.

## High Pressure Tab

Located between the valve body and the actuator mounting bracket, is a yellow tab labeled “High Pressure” see Fig. 21. This is for maintenance of the valve only.

If the valve stem begins leaking beneath the yellow tab the internal packing material must be replaced. The “High Pressure” tab is held on with two screws located under the mounting bracket.

To replace the packing material, all water pressure must be removed from the valve assembly and the assembly must be isolated from the system water. Then remove the actuator and bracket, then remove the two screws holding the “High Pressure” tab in place.

At this point the packing material can be removed and replaced just like any other valve assembly. The packing material is not available from Raypak.




Fig. 21: High Pressure Tab

## Actuator


The ELODRIVE actuator has a manual override for the valve. The label located over the silver colored primary label states, “Please read manual before using manual override”. Using the Allen wrench supplied with the loose valve, place it in the hexagonal opening under the label. See Fig. 22.

By pressing the red release button on the tail of the actuator and simultaneously rotating the Allen wrench you can rotate the ball clockwise. Once you release or remove the Allen wrench the ball will return to its original position by way of the “spring return”. This is an easy way to determine if the ball is oriented properly inside of the valve.



Fig. 22: Actuator


# Cold Water Start Troubleshooting Guide



# Typical Cold Water Start Piping


**NOTES:**

1. LOCATE UNIONS TO FACILITATE SERVICING OF PLUMBING SIDE.
2. PLUMB SWING CHECK VALVE IN GRAVITY-CLOSED POSITION.
3. PIPE ALL RELIEF VALVES TO DRAIN, OR AS LOCAL CODES REQUIRE.
4. BUFFER TANK REQUIRED WHEN WATER VOLUME IN BOILER LOOP IS NOT ADEQUATE TO PROVIDE STABLE TEMPERATURE CONTROL. CONSULT FACTORY FOR TANK SIZING.
5. SYSTEM FLOW MUST EXCEED HEATER FLOW AT ALL TIMES.





# Wiring Diagrams—Cold Water Start

## COLD START CONTROL ASSEMBLY




## HEATER INTERFACE WIRING FOR CWS OR CWR



## RAYTHERM

(SOME COMPONENTS REMOVED FOR CLARITY)



# COLD WATER START— MULTIPLE HEATER (Maximum 4 heaters)

## Materials Included

- 1 Cold Start Control Box
- 1 Multi-Boiler Interlock Box
- 1 Water Sensor & Well
- 1 Three-way Diverting Valve assembly with Actuator

**NOTE:** Flanges, bolts and gaskets for flanged valves supplied by others.

## Installation

### Mounting the Control Boxes

Cold Start Control and Multi-Boiler Interlock should be mounted in such a manner as to allow for easy access for wiring of the boiler interlock connections.

### Installing the Temperature Sensor

Temperature sensor to be installed in a drywell with thermal paste at the location indicated in the diagram on page 21 to ensure proper operation of the control system. Installer must ensure the drywell extends at least 2 inches into the water flow path. Sensor wiring must be run in separate conduit from line voltage and should be a minimum of 18 AWG shielded cable. Refer to diagram on page 22 for wiring information.

## Installing the Three-way Valve

Install three-way diverting valve into common boiler piping manifold as shown in the diagram on page 18. Boiler common outlets to be connected at port AB. Discharge to system from port A with bypass port being port B. Common pipe sizing may be larger than three-way valve port connections requiring the use of increasers for installation (see Table B for valve sizing). It is recommended that three-way valve be installed as near the main system piping as is feasible. Route control wiring in separate conduit to the Cold Water Start control box and wire as shown in the diagram on page 19.

## Connecting Power to the Controller

Installer to provide a dedicated 120V circuit with local disconnect to the Cold Water Start Control. Refer to wiring Fig. 9 on page 8 for detailed instruction.

## Connecting Cold Water Start to Multi-Heater Interlock Box

Installer to provide four 18AWG stranded wires between pins 7-10 on the Cold Start Control and 7-10 on the Multi-Boiler Interlock as shown in the diagram on page 22. Do not use solid core wire when wiring any portion of the Cold Start Multi-Boiler system.

## Connecting Heater to Cold Water Start Multi-Heater Interlock

Installer to provide five 18AWG stranded wires between each boiler and Multi-Boiler Interlock box. Wiring to be run in separate conduit from line voltage to ensure proper operation. Refer to the diagram on page 22 for connection points depending on Raypak product being used.

Total Load (MBTU)	Valve Size	Minimum Pipe Size	Cv	Flow Rate (gpm)	Valve Pressure Drop	ΔT @ Max Size	ΔT @ Min. Size	Order No.
600-1000	2" NPT	2	57	70	3.5 ft	22	14.4	012228
1001-1800	2.5" NPT	2.5	74	100	4.2 ft	30.2	16.8	012229
1801-2600	2.5" NPT	3	100	150	5.2 ft	29.1	20.1	012230
2601-4000	4" FLG*	4	152	220	4.8 ft	30.5	22.9	012231
4001-6000	4" FLG*	4	254	330	3.9 ft	30.5	20.3	012232
6001-8000	4" FLG*	6	327	440	4.2 ft	30.5	22.5	012233

Standard boiler pump options offered by Raypak may **NOT** be appropriate for these applications.

\***CAUTION:** Approved for closed loop systems only.

**Table B: Valve Sizing Chart**


## Actuator to Valve Orientation

Install the actuator so that the tail is pointing horizontally as shown in Fig. 26 or is pointing down. DO NOT mount it so that the tail is pointing up as shown in Fig. 20. Doing so will allow water and debris to collect in the cup where the wiring exits the actuator, potentially causing damage.

## Three-Way Valve Ball Orientation

The ball orientation must be verified prior to mounting the flanged valve into the piping system. With the flanged four-inch valve it is a fairly simple procedure. Do not use the groove on the end of the drive linkage to verify.

First, remove the actuator by removing the wing-nut underneath the mount bracket near the tail. Second, loosen the locking bolt on top of the actuator that clamps to the drive linkage. See Fig. 23.



**Fig. 23: Removing the Actuator (Elodrive)**

Once this has been done, remove the actuator by lifting straight off the drive linkage shaft.


Now the ball position must be verified. Using pliers, grasp the base of the drive linkage. While looking into port AB, rotate the drive linkage counterclockwise about 45 degrees. See Fig. 24. You should see two partial openings similar to Fig. 18.

If you do not see the two partial openings after 45 degrees of rotation, continue rotating until you do. Once you see the two partial openings, STOP. Now rotate the shaft in the reverse direction (clockwise) until you can see straight through to valve from port AB to port A.


Reinstall the actuator and bracket assembly in reverse order, and ensure that the ball assembly is properly oriented. Mount the flanged valve into your piping system in accordance with this manual.

## Valve Installation

To properly install this valve port "AB" must be connected to the combined outlet of the heater(s); and port "B" must be attached to the bypass between the combined inlet and the combined outlet, as shown on page 21. The valve body has the port designators cast into the drive linkage housing. See Fig. 25.



**Fig. 24: Rotating the Drive Linkage**



**Fig. 25: Valve Orientation**

## 4-Inch Valve Orientation

The valve must be installed so that the combined boiler outlets enter through Port "AB" (See Fig. 26). Port "B" is the bypass port and port "A" is the return to the system (port designations are cast into the stem of the valve body). The valve body should be installed so that the actuator input shaft is in the vertical or horizontal position. The Actuator stem should never be hanging downward.

The actuator, as shipped from the factory, is in the horizontal position when the valve is installed as shown in Fig. 26. The actuator position can be changed to suit job site conditions.

Under no circumstances should the actuator be positioned such that the electrical connection is pointing upwards (see Fig. 20) as this can allow for moisture or debris to enter the actuator assembly and potentially damage the actuator.

Before installing into the piping system, verify the valve is positioned properly by referring to Fig. 26 and the diagram on page 21.

## Connecting the Actuator

The 4-inch valve is shipped loose, and must be field wired. Connect the actuator leads to the Cold Water Start control panel, as indicated in the wiring diagram on Page 16.




Fig. 26: Valve Orientation (Elodrive Actuator)




Fig. 27: Elodrive actuator used on 4" valves (Actuator shown in full system flow position.)

The actuator for the 4" valves rotates opposite to the direction of the smaller actuators. On an Elodrive actuator, Side A must be facing away from the valve.





Fig. 28: Rotational Setting for Elodrive Actuator Used on 4" Valves


# Typical Cold Water Start Multiple Heater Piping

**NOTES:**

1. PLUMB SWING CHECK VALVE IN GRAVITY-CLOSED POSITION.
2. PIPE ALL RELIEF VALVES TO DRAIN, OR AS LOCAL CODES REQUIRE.
3. LOCATE UNIONS TO FACILITATE SERVICING OF PLUMBING SIDE.
4. BUFFER TANKS MAY BE REQUIRED TO PROVIDE STABLE TEMPERATURE CONTROL ON SYSTEMS WITH VARIABLE FLOW OR LOW WATER VOLUME. CONSULT FACTORY FOR SELECTION CRITERIA.
5. MAXIMUM 4 TIMES THE PIPE DIAMETER OR 12", WHICHEVER IS LESS.
6. SYSTEM FLOW MUST EXCEED HEATER FLOW AT ALL TIMES.



# Wiring Diagram Multiple Heater



FOR HEATER INTERFACE WIRING  
(SEE PAGE 17)

MULTIPLE BOILER CONTROL ASSEMBLY

# COLD WATER RUN

**NOTE:** After testing at the factory it may be prudent to ship the piping assembly disassembled and attached to the heater pallet. This is done to avoid shipping damage and it must be reassembled on the jobsite. Use Fig. 29 to assist you in reassembling the piping.




Fig. 29: Cold Water Run Assembly

## Purpose

The Cold Water Run system utilizes a variable-speed pump to inject the proper amount of water from the main system loop into the heater to maintain the optimum inlet temperature. This approach allows the full capacity of the heater to be utilized to meet the system load, while at the same time continuously maintaining the optimum inlet water temperature to prevent condensation.

## Typical Cold Water Run Applications

- Swimming pools.
- Any system with steady-state (or “consistent”) return water temperature below 105°F.

## CWR vs. CWS

- Cold water start is for transient cold water operation.
- Cold water run is for continuous operation below 105°F system return temperature.
- Cold water start maintains design flow rate at system design temperature but reduces boiler flow rate during heavy bypass operation.
- Cold water run maintains constant design flow rate in the boiler.

## Installation

Before beginning the installation, it's important to first inspect the system and determine what materials you will need. Some parts are included with the controller while others you will need to provide.

## Installation Codes

Installations must be in accordance with local, state, provincial, and national codes, laws, regulations and ordinances. In the absence of local codes, installations must be in accordance with the latest editions of the:

- National Fuel Gas Code, ANSI Z223.1/NFPA 54
- National Electrical Code, ANSI/NFPA 70
- For Canada only: CAN/CSA B149 Installation Code and CSA C22.1 C.E.C. Part 1 and Part 2

## Mounting the Control Box

**NOTE:** The heater should not be located in an area where possible water leakage will result in damage to the area adjacent to the heater or to the structure. When such locations cannot be avoided, it is recommended that a suitable drain pan, with adequate drainage, be installed under the heater. The pan must not restrict combustion air flow.

The control box should be mounted on the side of the heater to which the system piping and pump assemblies are to be attached as shown in Figs. 4–8 on pages 7 & 8. The controller should be mounted so as to provide maximum support by using the mounting holes provided on the base of the controller to the side center brace on the heater. You will need to drill mounting holes for #10 hardware and 3/4” conduit access holes through the heater side panel for the routing of wiring and the sensor.

**CAUTION:** Remote mounted controller must be installed within 25 feet of wire length to the heater.

## Injector & Heater Pump Comparison

Heater Model	Heater Pump				Injector Pump		
	Flow	Temp. Rise	Press. Drop	Pump Model/Imp.	Flow	Temp. Rise	Pump Model-hp
302	32	16	2	112	13	40	1911-¼ hp
402	34	20	2	112	17	40	1911-¼ hp
502	42	20	2.3	1630/4.0	22	40	1911-¼ hp
652	55	20	4.1	1630/4.0	28	40	1911-¼ hp
752	63	20	5.7	1630/4.2	32	40	1911-¼ hp
902	76	20	8.4	1630/4.2	38	40	1911-¼ hp
992	83	20	5.2	1630/4.7	42	40	1911-¼ hp
1262	107	20	9.6	1630/4.7	54	40	1911-½hp
1532	120	22	12.4	1632/5.6	62	42	1911-½hp
1802	120	25	13	1632/5.6	68	45	1911-½hp
2002	132	26	19	1634/6.1	74	46	1935-¾hp
2072	132	27	19	1634/6.1	75	47	1935-¾hp
2342	132	30	21.4	1634/6.1	80	50	1935-¾hp

Table C: Injector and Heater Pump Specifications—Hi Delta

Heater Model	Heater Pump				Injector Pump		
	Flow	Temp. Rise	Press. Drop	Pump Model	Flow	Temp. Rise	Pump Model-hp
503	58	15	2.4	1611	29	30	1911-¼ hp
753	63	21	5.6	1611	44	30	1911-¼ hp
1003	87	20	8.2	1630	58	30	1911-½ hp
1253	86	25	12.2	1630	73	30	1911-½ hp
1503	100	26	18.5	1632	87	30	1911-½ hp
1753	109	28	26	1634	102	30	1911-½ hp
2003	116	30	36.2	1636	116	30	1935-¾ hp

Table D: Injector and Heater Pump Specifications—MVB

Heater Model	Heater Pump				Injector Pump		
	Flow	Temp. Rise	Press. Drop	Pump Model/Imp.	Flow	Temp. Rise	Pump Model-hp
926/962	79	20	8.5	1630/4.7	50	32	1911-¼ hp
1083/1125	90	21	12.0	1630/4.7	50	37	1911-¼ hp
1178/1223	90	22	12.5	1630/4.7	60	33	1911-½ hp
1287/1336	90	25	13.2	1630/4.7	60	37	1911-½ hp
1414/1468	90	27	14.0	1632/5.65	60	40	1911-½ hp
1571/1631	90	30	14.5	1632/5.65	60	45	1911-½ hp
1758/1826	90	34	15.4	1632/5.65	60	50	1911-½ hp
2100	172	20	11.0	1641/6.9	130	26	1935-¾hp
2500	200	21	15.8	1641/6.9	130	32	1935-¾hp
3001	200	25	16.7	1641/6.9	130	38	1935-¾hp
3500	200	29	17.5	1641/6.9	130	44	1935-¾hp
4001	200	33	18.7	1641/6.9	130	50	1935-¾hp

Table E: Injector and Heater Pump Specifications—Raytherm

## Check the Power Source

**WARNING:** Using a multi-meter, check the following voltages at the circuit breaker panel prior to connecting any equipment. Make sure proper polarity is followed and house ground is proven.




Fig. 30: Wiring Connections

Check the power source:

AC = 104 VAC Minimum, 126 VAC MAX  
 AB = 208 VAC Minimum, 252 VAC MAX  
 BC = 104 VAC Minimum, 126 VAC MAX




Fig. 31: Multi-meter

## Injector Pump Wiring

The 3-phase cold water run pump is shipped loose and must be field wired.

### Before Starting

1. Turn off power to the unit at the circuit breaker.
2. Turn off gas supply.
3. Shut off the water supply to the heater and, if necessary, drain water from the system.

4. Locate the pump junction box and wiring decal shown in Fig. 32.




Fig. 32: Pump Wiring Decal and Junction Box

5. Remove the pump junction box cover shown in Fig. 32 and locate the 9 wires inside.
6. Wire in accordance with the low voltage (230 VAC) decal located next to the pump junction box (do not connect high voltage 460 volt power to the control box).
7. In the absence of the pump mounted decal, use Table F to complete the wiring between the cold water run control box and the 3-phase injector pump. Use wire nuts (field supplied) to complete these connections and ensure that all connections are tight.

230 VAC 3 $\phi$ Line	Low Voltage Pump Wiring
Black	Orange (3) and Gray (9)
Red	Red (8) and White (2)
White	Pink (7) and Blue (1)
_____	Yellow (4) and Black (5) and Violet (6)
Green	Ground Lug

Table F: Cold Water Run Control Panel and Injector Pump Wiring




Fig. 33: Cold Water Run Control Panel and Injector Pump Wiring

8. Re-install the injector pump junction box cover.
9. Turn on the water and gas supply.
10. Turn the electrical supply on to the heater and to the cold water run system.
11. Turn heater on to receive a “call-for-heat” and verify the injector pump is rotating in the proper direction (clockwise). The pump volute has an arrow cast into the housing indicating the proper rotational direction. See Fig. 34.




Fig. 34: Directional Arrow

12. If the pump is rotating in the proper direction, secure the heater from installation.
13. If the pump is rotating incorrectly, turn off power and swap ONLY two of the line voltage leads into the pump (for example, swap the red and black leads). Confirm that the pump now rotates in the proper direction before proceeding.
14. Secure from installation.

## Injection Pump Cover Installation (Required for Outdoor Installation Only)

### Before Starting

1. Turn off power to the unit at the circuit breaker.
2. Turn off gas supply.
3. Shut off the water supply to the heater and, if necessary, drain water from the system.
4. Allow heater to cool down before attempting work.

In order to install the pump cover, you will need to rotate the pump body so that the electrical box is pointing downward, as outlined in the following steps:

1. Loosen and remove the eight (8) 9/16" bolts holding the pump body in place. See Fig. 35.




Fig. 35: Remove the eight bolts holding the pump body in place

2. Remove the pump body then rotate it so that the electrical box is pointing downward, ensuring not to damage the seal. See Figs. 36, 37 and 38.





Fig. 36: Remove the pump body



Fig. 37: Be sure not to damage the seal when removing or replacing the pump body




**Fig. 38: Reposition the pump body so that the electrical box points downward**

3. Insert and tighten all eight (8) bolts, securing the pump body in place.
4. You will now be able to install the pump cover. See Figs. 39 and 40.




**Fig. 40: Pump cover - angle view**




**Fig. 39: Place the cover on the pump**

# Typical Cold Water Run Piping - Heating Applications



- NOTES:
1. LOCATE UNIONS TO FACILITATE SERVICING OF PLUMBING SIDE.
  2. PLUMB SWING CHECK VALVE IN GRAVITY-CLOSED POSITION.
  3. PIPE ALL RELIEF VALVES TO DRAIN, OR AS LOCAL CODES REQUIRE.
  4. SYSTEM FLOW MUST EXCEED HEATER FLOW AT ALL TIMES.

# Typical Cold Water Run Piping - Pool Applications



- NOTES:
1. LOCATE UNIONS TO FACILITATE SERVICING OF PLUMBING SIDE.
  2. PLUMB SWING CHECK VALVE IN GRAVITY-CLOSED POSITION.
  3. PIPE ALL RELIEF VALVES TO DRAIN, OR AS LOCAL CODES REQUIRE.
  4. USE REDUCING TEES WHERE INDICATED.
  5. SYSTEM FLOW MUST EXCEED HEATER FLOW AT ALL TIMES.

MAIN	"A"
4"	12"
6"	18"
8"	18"
10"	24"

## Operation

- Run full system flow for two minutes.
- Initiate PID pump control to achieve target inlet temperature by slowing injector pump.
- Boiler  $\Delta T$  will not increase during bypass operation.
- If target temperature is not achieved after 7 minutes from “call for heat”, the system will shut down.




Fig. 41: Control Board

## Cold Run Sequence of Operation

1. Supply separate 220VAC, 1 phase, 60 Hz power for the Hitachi Inverter (blue-colored inverter), or 120VAC or 220VAC, 1 phase, 60 Hz power for the AC Tech Inverter (white-colored inverter).
2. Call for heat occurs at heater.
3. The heater outputs 24VAC to terminal 4 of terminal block 3 located in Cold Run controller.
4. Terminal 4 of TB 3 sends 24VAC to the coil of the SPST relay located in the cold run control panel.
5. The SPST relay coil is energized and closes the contacts allowing 24VAC from the Cold Run control transformer to be sent to the CFH terminal of the Cold Run circuit board.
  - a) A two second delay occurs from the CFH signal waiting to send power from terminal MC of the cold run circuit board.
6. 24 VAC is sent from terminal 2 of terminal block 3 to the NO contacts of the DPST relay located in the cold run control panel.
7. After the two second delay on the cold run circuit board, pin MC outputs a 24 VAC signal to terminal AL0 of the Hitachi inverter.
8. The AL0 relay closes and outputs a 24 VAC signal to the coil of the DPST relay located in the cold run control panel.
9. The DPST relay coil energizes and closes the NO contacts.
10. Once the NO contacts of the DPST close, the heater 24 VAC is sent back to the heater to complete the circuit (pin 3 of terminal block 3) and the interlock circuit (pin 1 & 2 of terminal block 3) allowing the heater to fire.
11. Pin SC of the cold run circuit board sends 10VDC to Pin 1 (Forward) on Hitachi Inverter.
12. PCS terminal on Inverter outputs 12VDC signal to the common terminal of the reset switch located on the bottom of the cold run control panel.
13. The 12VDC signal crosses over the reset switch and goes to Pin FS and to pin S1 on cold run circuit board.
14. Pin FR on the TVC board outputs 10VDC to pin O of the Inverter to drive injector pump at full speed for two-minutes waiting for the heater to reach full fire.
15. After the two-minute delay the 10VDC output signal from pin FR reduces to approximately 8VDC at the inverter thus slowing the pump to approximately 50 Hz.
16. The output signal continues to vary depending on the heater inlet temperature.

The heater will lockout and shut down if the set point on the inlet temperature is not achieved within 7 minutes from a call for heat.

The DIP switches on the Hitachi Inverter must be set as indicated on Fig. 42 below.





Fig. 42: DIP Switch Settings (Hitachi)


# Cold Water Run Troubleshooting Guide

**\*NOTE:** See wiring diagrams for proper supply voltage based on inverter used on heater.





# Wiring Diagram—Cold Water Run (AC Tech Inverter)



---

## REPLACEMENT PARTS

To order replacement parts, consult the Raypak Illustrated Parts Lists 9300.82 for Cold Water Start and 9300.83 for Cold Water Run.

**NOTE:** To receive the correct part, it is important that you state the model number and serial number when ordering.

Any part returned for replacement under standard company warranties must be properly tagged with RAYPAK return parts tag, completely filled in with the heater serial number, model number, etc., and shipped to the Company freight prepaid. If determined defective by the Company and within warranty, the part will be returned in kind or equal substitution, freight collect. Credit will not be issued.

**RAYPAK, INC.**  
**2151 Eastman Avenue**  
**Oxnard, CA 93030**

---



**[www.raypak.com](http://www.raypak.com)**

Raypak, Inc., 2151 Eastman Avenue, Oxnard, CA 93030 (805) 278-5300 Fax (805) 278-5468  
Litho in U.S.A.