



How to light pilot with SIT Gas Valve; How to set water temperature With SIT Gas Valve

WARNING!

AVOID ANY DAMAGE TO THE DEVICE (KNOCKS,FALLS,ETC.). IN CASE OF FALL OF THE VALVE, IT IS RECOMMENDED NOT TO USE IT.

WARNING!

- Do not tamper with sealed parts.
- Do not loosen assembly screws.
- Do not remove labels and marking.

WARNING!

Observe recommended torques.

Use only specified spanner grips when making the connections (see Fig. 1 and Fig. 2).

WARNING!

DO NOT OPERATE THE DEVICE WHEN THE STORAGE WATER HEATER IS NOT FILLED WITH WATER.

OPERATION



STOP!

It is imperative that you read and follow all safety warnings before lighting the pilot burner. Refer to ANSI Z21.10 and ANSI Z21.78.

WARNING!

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.

WARNING!

Make certain that the water heater is completely filled with water before attempting to ignite the pilot burner or otherwise operate the gas control.

Note: All knob settings referenced to the reference arrow marks (a) in Fig. 3.


IMPORTANT: Always start operation from the OFF position of the control knob.



CAUTION!

Wait a minimum of (5) five minutes before attempting to re-light the pilot burner after the gas control has been switched to the OFF position and/or the pilot flame has been extinguished. Repeat the pilot ignition sequence starting from the OFF position. (Fig. 3)

Pilot flame ignition

Start from the OFF position (Fig.3). Rotate the control knob counter-clockwise  to the PILOT position (Fig.4). Press and hold the ignition button PILOT (b) for thirty (30) seconds or more and simultaneously press several times the Piezo Igniter button (c) to light the pilot flame (Fig.5). Release the ignition button PILOT and make sure that the




Fig. 3: OFF position



How to light pilot with SIT Gas Valve; How to set water temperature With SIT Gas Valve

pilot flame remains lit. If it goes out, repeat the ignition process, starting from the OFF position.




Fig. 4: PILOT position







Fig. 5: Ignition button PILOT and Piezo Igniter button

Main burner ignition

Turn the control knob counter-clockwise  to the ON position (Fig.6). Gas will flow to the main burner when the water temperature stored within the appliance is lower than the set-point temperature.

Temperature setting

To increase the water temperature set-point rotate the control knob counter-clockwise  to the desired temperature setting (Fig.7). The gas path to the main burner opens when the water temperature within the appliance is lower than the temperature set-point.

To decrease the water temperature set-point, rotate the control knob clockwise  to the desired temperature setting (Fig.8). The gas path to the main burner opens when the water temperature within the appliance is lower than the temperature set-point.





Fig. 8: VERY HOT position

Note: Temperatures are approximate with a variance of $\pm 10^\circ\text{F}$. See Figures 6-8

160 degrees

This setting is very dangerous and will produce a scald in less than one second.

Stand-by position

To maintain a flame at the pilot burner with the main burner off, turn the control knob clockwise  to the PILOT position (Fig.9).




Fig. 6: ON position

78 degrees




Fig. 7: LOW position

120 degrees




Fig. 7a: HOT position

135 degrees




Fig. 9: PILOT position





Fig. 10: OFF position

Turning off

Turn the control knob clockwise  to the OFF position (Fig.10).