

**COMMERCIAL
MODELS: 1688 THRU 4000**

CATALOG NO. 9300.55
Effective: 01-01-15
Replaces: 08-03-10

RAYPAK ILLUSTRATED PARTS LIST

MODEL SIZES: 1688, 1813, 2001, 2188, 2406, 2688, 3000, 3291, 3656, 4000

MODEL TYPES: T, Ta, Tb, WT, THWS, TIP

DATES OF MANUFACTURE: *1968 THRU 9-1-84 EXCEPT AS NOTED.


MODELS: 1688, 1968 THRU 1969.

MODELS: 2188, 2688 & 3656, 1968 THRU 7-2-80.

MODELS: 3291, 1968 THRU 1983.

*Service parts listed in this pamphlet are for units built before 7-2-80


THE PARTS LISTED ARE FOR STANDARD EQUIPMENT FOR THIS MODEL TYPE. RAYPAK RESERVES THE RIGHT TO SUBSTITUTE, DELETE OR CHANGE ANY PART WITHOUT NOTIFICATION. THE ADDITION OF OPTIONS MAY ALSO CHANGE SOME OF THE PARTS. ORDER REPLACEMENT PARTS FROM ACTUAL HEATER COMPONENTS.




FOR DETAILED INSTRUCTIONS ON "HOW TO USE YOUR RAYPAK ILLUSTRATED PARTS LIST" SEE 9001.10 INSTRUCTION SHEET.




Raypak, Inc., 2151 Eastman Avenue, Oxnard, CA 93030
(805) 278-5300 Fax (800) 872-9725
Litho In U.S.A.



**GENERAL CONTROLS J998 PILOT
USED WITH G60 PILOT SAFETY**



**ITT 262AD27 PILOT
USED WITH A100S PILOT SAFETY**



CALL OUT	DESCRIPTION	1688	1813	2001	2188	2406
B	BURNER TRAY**					
1-B	Burner Tray w/Burner (Sea Level)*	N/A	N/A	N/A	N/A	N/A
	Burner Tray w/o Burner (Sea Level)*	N/A	N/A	N/A	N/A	N/A
2-B	Burner Spacer/Hold Down Kit	N/A	N/A	N/A	N/A	N/A
3-B	Burner	301210/108	301210/116	301210/128	301210/140	301210/154
4-B	Burner Orifice Nat. #49 (Sea Level)*	350078/108	350078/116	350078/128	350078/140	350078/154
	Burner Orifice Pro. #57 (Sea Level)*	350083/108	350083/116	350083/128	350083/140	350083/154
5-B	Extension Orifice/Burner	N/A	N/A	N/A	N/A	N/A
C	CONTROLS					
1-C	Manual Hi Limit (T, Tb, TIP, THWS)	007144F	007144F	007144F	007144F	007144F
	Auto Reset Dualstat (WT)	N/A	004092F	004092F	004092F	004092F
	Manual Reset Dualstat	N/A	N/A	N/A	N/A	N/A
	Adj. Auto Hi Limit (WT)		007141F	007141F	007141F	007141F
	Controller 2 Stage (Tb)	N/A	007392F	007392F	007392F	007392F
	Controller (T)	N/A	N/A	N/A	N/A	N/A
	Controller (TIP/THWS)	N/A	N/A	N/A	N/A	N/A
	Controller (Tx, w/B3) See Chart Page 7					
	Controller (Tx w/B5)	N/A	N/A	N/A	N/A	N/A
2-C	Flow Switch	007142F	007142F	007142F	007142F	007142F
3-C	Low Water Cut Off	N/A	006202F	006202F	006202F	006202F
4-C	Flow Switch Paddle					
	McDonnell Miller	004079F	004079F	004079F	004079F	004079F
	Taco	010026F	010026F	010026F	010026F	010026F
G	GAS VALVES	SEE GAS VALVE REPLACEMENT CHART				
H	HEAT EXCHANGER					
1-H	Heat Exchanger Assy. Cast Iron 2 Pass	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Brass 2 Pass	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Cast Iron 2 Pass Cupro	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Brass 2 Pass Cupro	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Cast Iron 1 Pass	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Brass 1 Pass	N/A	N/A	N/A	N/A	N/A
2-H	Inlet/Outlet Header Cast Iron 2 Pass	N/A	N/A	N/A	N/A	N/A
	Inlet/Outlet Header Brass 2 Pass	N/A	N/A	N/A	N/A	N/A
3-H	Inlet/Outlet Header Cast Iron 1 Pass	N/A	N/A	N/A	N/A	N/A
	Inlet/Outlet Header Brass 1 Pass	N/A	N/A	N/A	N/A	N/A
4-H	Return Header Cast Iron 2 Pass	N/A	N/A	N/A	N/A	N/A
	Return Header Brass 2 Pass	N/A	N/A	N/A	N/A	N/A
5-H	Tube Bundle	N/A	N/A	N/A	N/A	N/A
	Tube Bundle Cupro Nickle	N/A	N/A	N/A	N/A	N/A
6-H	Heat Exchanger Tube	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Tube Cupro Nickle	N/A	N/A	N/A	N/A	N/A
7-H	Baffle Kit	N/A	N/A	N/A	N/A	N/A
8-H	Stud Bolt Kit	001052F	001052F	001052F	001052F	001052F
9-H	Header Gasket	001054F	001054F	001054F	001054F	001054F
10-H	Adapter Inlet/Outlet Cast Iron 2 Pass	002088F	002088F	002088F	002088F	002088F
	Adapter Inlet/Outlet Brass 2 Pass	002087F	002087F	002087F	002087F	002087F
11-H	Adapter Outlet Brass 1 Pass	005399F	005399F	005399F	005399F	005399F
12-H	Adapter Inlet/Outlet Brass 2 Pass TIP	N/A	N/A	N/A	N/A	N/A
13-H	Adapter Gasket 2 Pass	N/A	005891F	005891F	005891F	005891F
	Adapter Gasket 1 Pass	N/A	014486F	014486F	014486F	014486F
14-H	Sensor Well 1/2 OD	350339	350339	350339	350339	350339
	Sensor Well 5/8 OD	350337	350337	350337	350337	350337
15-H	Well Retaining Clip	300203	300203	300203	300203	300203
J	J-BOX					
1-J	J-Box D-3	N/A	N/A	N/A	N/A	N/A
	J-Box E-8/E-9	N/A	N/A	N/A	N/A	N/A
	J-Box C2,C3 IRI	N/A	N/A	N/A	N/A	N/A
2-J	Transformer E8 & E9	006533F	006533F	006533F	006533F	006533F
	Spark Generator C2, C3 IRI	007361F	007361F	007361F	007361F	007361F
3-J	Relay SPST	007377F	007377F	007377F	007377F	007377F
	Relay DPDT C2 (Not Shown)	650117	650117	650117	650117	650117
	Relay DPDT IRI (Not Shown)	N/A	N/A	N/A	N/A	N/A
4-J	Toggle Switch (Not Shown)	008079F	008079F	008079F	008079F	008079F

*FOR ALTITUDES ABOVE 2,000 FEET ABOVE SEA LEVEL, CONSULT THE FACTORY.

**REPLACEMENT BURNER TRAYS ARE BUILT FOR SEA LEVEL, NATURAL GAS APPLICATIONS UNLESS OTHERWISE SPECIFIED AT THE TIME THE ORDER IS PLACED.

CALL OUT	DESCRIPTION	2688	3000	3291	3656	4000
B	BURNER TRAY**					
1-B	Burner Tray w/Burner (Sea Level)*	N/A	N/A	N/A	N/A	N/A
	Burner Tray w/o Burner (Sea Level)*	N/A	N/A	N/A	N/A	N/A
2-B	Burner Spacer/Hold Down Kit	N/A	N/A	N/A	N/A	N/A
3-B	Burner	301210/172	301210/192	301210/210	301210/234	301210/256
4-B	Burner Orifice Nat. #49 (Sea Level)*	350078F/172	350078F/192	350078F/210	350078F/234	350078F/256
	Burner Orifice Pro.#57 (Sea Level)*	350083F/172	350083F/192	350083F/210	350083F/234	350083F/256
5-B	Extension Orifice/Burner	N/A	N/A	N/A	N/A	N/A
C	CONTROLS					
1-C	Manual Hi Limit (T, Tb, TIP, THWS)	007144F	007144F	007144F	007144F	007144F
	Auto Reset Dualstat (WT)	004092F	004092F	004092F	004092F	004092F
	Manual Reset Dualstat	N/A	N/A	N/A	N/A	N/A
	Adj, Auto Hi Limit (WT)	007141F	007141F	007141F	007141F	007141F
	Controller 2 Stage (Tb)	007392F	007392F	007392F	007392F	007392F
	Controller (T)	N/A	N/A	N/A	N/A	N/A
	Controller (TIP/THWS)	N/A	N/A	N/A	N/A	N/A
	Controller (Tx, w/B3) See Chart Page 6					
	Controller (Tx w/B5)	N/A	N/A	N/A	N/A	N/A
2-C	Flow Switch	007142F	007142F	007142F	007142F	007142F
3-C	Low Water Cut Off	006202F	006202F	006202F	006202F	006202F
4-C	Flow Switch Paddle					
	McDonnell Miller	004079F	004079F	004079F	004079F	004079F
	Taco	010026F	010026F	010026F	010026F	010026F
G	GAS VALVES	SEE GAS VALVE REPLACEMENT CHART				
H	HEAT EXCHANGER					
1-H	Heat Exchanger Assy. Cast Iron 2 Pass	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Brass 2 Pass	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Cast Iron 2 Pass Cupro	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Brass 2 Pass Cupro	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Cast Iron 1 Pass	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Assy. Brass 1 Pass	N/A	N/A	N/A	N/A	N/A
2-H	Inlet/Outlet Header Cast Iron 2 Pass	N/A	N/A	N/A	N/A	N/A
	Inlet/Outlet Header Brass 2 Pass	N/A	N/A	N/A	N/A	N/A
3-H	Inlet/Outlet Header Cast Iron 1 Pass	N/A	N/A	N/A	N/A	N/A
	Inlet/Outlet Header Brass 1 Pass	N/A	N/A	N/A	N/A	N/A
4-H	Return Header Cast Iron 2 Pass	N/A	N/A	N/A	N/A	N/A
	Return Header Brass 2 Pass	N/A	N/A	N/A	N/A	N/A
5-H	Tube Bundle	N/A	N/A	N/A	N/A	N/A
	Tube Bundle Cupro Nickle	N/A	N/A	N/A	N/A	N/A
6-H	Heat Exchanger Tube	N/A	N/A	N/A	N/A	N/A
	Heat Exchanger Tube Cupro Nickle	N/A	N/A	N/A	N/A	N/A
7-H	Baffle Kit	N/A	N/A	N/A	N/A	N/A
8-H	Stud Bolt Kit	001052F	001052F	001052F	001052F	001052F
9-H	Header Gasket	001054F	001054F	001054F	001054F	001054F
10-H	Adapter Inlet/Outlet Cast Iron 2 Pass	002088F	002088F	002088F	002088F	002088F
	Adapter Inlet/Outlet Brass 2 Pass	002087F	002087F	002087F	002087F	002087F
11-H	Adapter Outlet Brass 1 Pass	005399F	005399F	005399F	005399F	005399F
12-H	Adapter Inlet/Outlet Brass 2 Pass TIP	N/A	N/A	N/A	N/A	N/A
13-H	Adapter Gasket 2 Pass	005891F	005891F	005891F	005891F	005891F
	Adapter Gasket 1 Pass	014486F	014486F	014486F	014486F	014486F
14-H	Sensor Well 1/2 OD	350339	350339	350339	350339	350339
	Sensor Well 5/8 OD	350337	350337	350337	350337	350337
15-H	Well Retaining Clip	300203	300203	300203	300203	300203
J	J-BOX					
1-J	J-Box D-3	N/A	N/A	N/A	N/A	N/A
	J-Box E-8/E-9	N/A	N/A	N/A	N/A	N/A
	J-Box C2,C3 IRI	N/A	N/A	N/A	N/A	N/A
2-J	Transformer E8 & E9 40VA	006533F	006533F	006533F	006533F	006533F
	Transformer ignition C2, C3 IRI	600157	600157	600157	600157	600157
3-J	Relay SPST	007377F	007377F	007377F	007377F	007377F
	Relay DPDT C2 (Not Shown)	650117	650117	650117	650117	650117
	Relay DPDT IRI (Not Shown)	N/A	N/A	N/A	N/A	N/A
4-J	Toggle Switch (Not Shown)	008079F	008079F	008079F	008079F	008079F

*FOR ALTITUDES ABOVE 2,000 FEET ABOVE SEA LEVEL, CONSULT THE FACTORY.

**REPLACEMENT BURNER TRAYS ARE BUILT FOR SEA LEVEL, NATURAL GAS APPLICATIONS UNLESS OTHERWISE SPECIFIED AT THE TIME THE ORDER IS PLACED.

CALL OUT	DESCRIPTION	1688	1813	2001	2188	2406
M	MISCELLANEOUS					
1-M	PRV 60 PSI (T, Tb, Tx, Tc)	N/A	007753F	007754F	007754F	007754F
	PRV 125 PSI (WT, THWS, TIP)	007758F	007758F	007758F	007758F	007758F
2-M	Delimiting Kit	052870F	052870F	052870F	052870F	052870F
3-M	T & P Gauge (T, Tb, Tx)	007205F	007205F	007205F	007205F	007205F
	T & P Gauge (WT, THWs, TIP, Tc)	007399F	007399F	007399F	007399F	007399F
4-M	Pump w/Volute Bronze	N/A	N/A	N/A	N/A	N/A
	Pump w/Volute CIBF	N/A	N/A	N/A	N/A	N/A
P	PILOT					
	D3 A100S IGNITION					
1-P	Pilot Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Pro	N/A	N/A	N/A	N/A	N/A
2-P	Pilot Orifice Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Orifice Pro	N/A	N/A	N/A	N/A	N/A
3-P	Thermocouple	N/A	N/A	N/A	N/A	N/A
4-P	Ignition Control	N/A	N/A	N/A	N/A	N/A
5-P	Pilot Mounting Bracket (Not Shown)	N/A	N/A	N/A	N/A	N/A
6-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
	C1 RA890F TORCH IGNITION (NOT SHOWN)					
1-P	Pilot Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Pro	N/A	N/A	N/A	N/A	N/A
2-P	Pilot Orifice Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Orifice Pro	N/A	N/A	N/A	N/A	N/A
3-P	Thermocouple	600003	600003	600003	600003	600003
4-P	Ignition Control (complete)	008702F	008702F	008702F	008702F	008702F
	Amplifier Flame Rectification C2	008092F	008092F	008092F	008092F	008092F
5-P	Pilot Mounting Bracket	N/A	N/A	N/A	N/A	N/A
6-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
	C2 RA890F/C3 RA890H IGNITION (NOT SHOWN)					
1-P	Pilot Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Pro	002812F	002812F	002812F	002812F	002812F
2-P	Pilot Orifice Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Orifice Pro	N/A	N/A	N/A	N/A	N/A
3-P	Ignition Control C2, C3 (complete)	008702F	008702F	008702F	008702F	008702F
	Amplifier Flame Rectification C2	008092F	008092F	008092F	008092F	008092F
4-P	Pilot Mounting Bracket	N/A	N/A	N/A	N/A	N/A
5-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
	E8/E9 G60 IGNITION					
1-P	Pilot Nat (E8/E9)	N/A	N/A	N/A	N/A	N/A
	Pilot Pro (E8)	N/A	N/A	N/A	N/A	N/A
2-P	Pilot Orifice Nat (E8/E9)	N/A USE 1-P				
	Pilot Orifice Pro (E8)	N/A	N/A	N/A	N/A	N/A
3-P	Sensor Probe	N/A	N/A	N/A	N/A	N/A
4-P	Sensor Cable (Not Shown)	N/A	N/A	N/A	N/A	N/A
5-P	Ignition Control	600559F	600559F	600559F	600559F	600559F
6-P	Circuit Breaker (E8 Only)	N/A	N/A	N/A	N/A	N/A
7-P	Pilot Mounting Bracket (Not Shown)	N/A	N/A	N/A	N/A	N/A
8-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
R	REFRACTORY					
1-R	Refractory Block Kit	N/A	001007F	001008F	001029F	001009F
2-R	Refractory Retainer Kit	N/A	000977F	000978F	001050F	000979F
S	SHEETMETAL					
1-S	Drafthood Top Assy (Includes Flue Collector)	N/A	N/A	N/A	N/A	N/A
2-S	Flue Collector	N/A	002717F	002718F	002719F	002720F
3-S	J-Box Sheetmetal	N/A	N/A	N/A	N/A	N/A
	J-Box Sheetmetal C2	008703F	008703F	008703F	008703F	008703F

CALL OUT	DESCRIPTION	2688	3000	3291	3656	4000
M	MISCELLANEOUS					
1-M	PRV 60 PSI (T, Tb, Tx, Tc)	007755F	007755F	007755F	007755F	007755F
	PRV 125 PSI (WT, THWS, TIP)	007758F	007759F	007759F	007759F	007759F
2-M	Delimiting Kit	052870F	052870F	052870F	052870F	052870F
3-M	T & P Gauge (T, Tb, Tx)	007205F	007205F	007205F	007205F	007205F
	T & P Gauge (WT, THWs, TIP, Tc)	007399F	007399F	007399F	007399F	007399F
4-M	Pump w/Volute Bronze	N/A	N/A	N/A	N/A	N/A
	Pump w/Volute CIBF	N/A	N/A	N/A	N/A	N/A
P	PILOT					
	D3 A100S IGNITION					
1-P	Pilot Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Pro	N/A	N/A	N/A	N/A	N/A
2-P	Pilot Orifice Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Orifice Pro	N/A	N/A	N/A	N/A	N/A
3-P	Thermocouple	N/A	N/A	N/A	N/A	N/A
4-P	Ignition Control	N/A	N/A	N/A	N/A	N/A
5-P	Pilot Mounting Bracket (Not Shown)	N/A	N/A	N/A	N/A	N/A
6-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
	C1 RA890F TORCH IGNITION (NOT SHOWN)					
1-P	Pilot Nat	002805F	002805F	002805F	002805F	002805F
	Pilot Pro	002806F	002806F	002806F	002806F	002806F
2-P	Pilot Orifice Nat	600529F	600529F	600529F	600529F	600529F
	Pilot Orifice Pro	600528F	600528F	600528F	600528F	600528F
3-P	Thermocouple	600003	600003	600003	600003	600003
4-P	Ignition Control (complete)	008702F	008702F	008702F	008702F	008702F
	Amplifier Flame Rectification C2	008092F	008092F	008092F	008092F	008092F
5-P	Pilot Mounting Bracket	N/A	N/A	N/A	N/A	N/A
6-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
	C2 RA890F/C3 RA890H IGNITION (NOT SHOWN)					
1-P	Pilot Nat	N/A	N/A	N/A	N/A	N/A
	Pilot Pro	002812F	002812F	002812F	002812F	002812F
2-P	Pilot Orifice Nat	600529F	600529F	600529F	600529F	600529F
	Pilot Orifice Pro	600528F	600528F	600528F	600528F	600528F
3-P	Ignition Control C2 (complete)	008702F	008702F	008702F	008702F	008702F
	Amplifier Flame Rectification C2	008092F	008092F	008092F	008092F	008092F
4-P	Pilot Mounting Bracket	N/A	N/A	N/A	N/A	N/A
5-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
	E8/E9 G60 IGNITION					
1-P	Pilot Nat (E8/E9)	N/A	N/A	N/A	N/A	N/A
	Pilot Pro (E8)	N/A	N/A	N/A	N/A	N/A
2-P	Pilot Orifice Nat (E8/E9)	N/A USE 1-P				
	Pilot Orifice Pro (E8)	N/A	N/A	N/A	N/A	N/A
3-P	Sensor Probe	N/A	N/A	N/A	N/A	N/A
4-P	Sensor Cable (Not Shown)	N/A	N/A	N/A	N/A	N/A
5-P	Ignition Control	600559F	600559F	600559F	600559F	600559F
6-P	Circuit Breaker (E8 Only)	N/A	N/A	N/A	N/A	N/A
7-P	Pilot Mounting Bracket (Not Shown)	N/A	N/A	N/A	N/A	N/A
8-P	Pilot Tube (Specify Length)	400013	400013	400013	400013	400013
R	REFRACTORY					
1-R	Refractory Block Kit	N/A	N/A	N/A	N/A	N/A
2-R	Refractory Retainer Kit	N/A	N/A	N/A	N/A	N/A
S	SHEETMETAL					
1-S	Draft Hood Top Assy (Includes Flue Collector)	N/A	N/A	N/A	N/A	N/A
2-S	Flue Collector	N/A	N/A	N/A	N/A	N/A
3-S	J-Box Sheetmetal	N/A	N/A	N/A	N/A	N/A
	J-Box Sheetmetal C2	008703F	008703F	008703F	008703F	008703F

CALL OUT	DESCRIPTION	PART NUMBER	I, THWS, TIP									
			1688	1813	2001	2188	2406	2688	3000	3291	3656	4000
G	GAS VALVES											
	Manual "B" Valve 1/8"	007195F	1	1	1	1	1	1	1	1	1	1
	Manual "A" Valve 1 1/2"	600881		1	1	1	1					
	Manual "A" Valve 2"	600882						1	1	1	1	1
	Pressure Regulator Nat 1/8"	600217	1	1	1	1	1	1	1	1	1	1
	Pressure Regulator Pro 1/8"	003568F	1	1	1	1	1	1	1	1	1	1
	Pressure Regulator Nat 1 1/2"	600044		1								
	Pressure Regulator Pro 1 1/4"	003571F		1	1	1	1					
	Pressure Regulator Nat 2"	600036			1	1	1	1	1			
	Pressure Regulator Pro 1 1/2"	003617F						1	1			
	Pressure Regulator Pro 2 1/2"	600078								1	1	1
	Pressure Regulator Pro 2"	003604F								1	1	1
	Gas Valve Body Pro 1"	014014F		1	1							
	Gas Valve Body Pro 1 1/4"	014015F				1	1					
	Gas Valve Body Nat 1 1/2"	600452		1	1							
	Gas Valve Body Pro 2"	600453				1	1	1	1	1	1	1
	Comb. Gas Valve Pro 1"	003573F										
	Comb. Gas Valve Nat 1 1/2"	600633										
	Comb. Gas Valve Pro 1"	N/A										
	Actuator, Modulation	600449		1	1	1	1	1	1	1	1	1
	Actuator, On-Off	011908F										
	Gas Pressure Switch (high)	007188F						1	1	1	1	1
	Pilot Gas Valve	600562		1	1	1	1	1	1	1	1	1
	Comb. Gas Valve 2-Stage Nat 1 1/4"	600656										
	Comb. Gas Valve 2-Stage Pro 1"	003607F										
	Comb. Gas Valve 2-Stage Nat 1 1/2"	600850										
	Comb. Gas Valve 2-Stage Pro 1 1/4"	003608F										
	Actuator, 2 Stage	600458										
*	Gas Pressure Switch (low)	007187F		1	1	1	1	1	1	1	1	1
	Gas Pressure Switch (high)	007188F		1	1	1	1	1	1	1	1	1
*	Lube/Cock Valve 2"	600327		2	2	2	2	2	2			
*	Lube/Cock Valve 2 1/2"	600328								2	2	2
*	Gas Vent Valve 1"	011914F		1	1	1	1	1	1			
*	Gas Vent Valve 1 1/4"	600548								1	1	1

B-3 (W902) CONTROLLER	PART #
Outdoor Reset Controller (W902)	N/A
Outdoor Temp Sensor	N/A
Water Sensor	N/A
Motor (M944J) (B3-a)	N/A
Motor (M944J) (B3-2)	N/A
Potentiometer	N/A
Auxiliary End Switch (B3-1)	N/A
Auxiliary End Switch (B3-2)	N/A
Actuator	600449
Relay-DPDT 120V	008145F

CALL OUT	DESCRIPTION	PART NUMBER	WT										Tb									
			1688	1813	2001	2188	2406	2688	3000	3291	3656	4000	1688	1813	2001	2188	2406	2688	3000	3291	3656	4000
G	GAS VALVES																					
	Manual 'B' Valve 1/8"	007195F	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
	Manual 'A' Valve 1 1/2"	600881		1	1	1	1	1														
	Manual 'A' Valve 2"	600882						1	1	1	1	1	1									
	Pressure Regulator Nat 1/8"	600217	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
	Pressure Regulator Pro 1/8"	003568F	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
	Pressure Regulator Nat 1 1/2"	600044																				
	Pressure Regulator Pro 1 1/4"	003571F						1	1													
	Pressure Regulator Nat 2"	600036						1	1	1	1	1										
	Pressure Regulator Pro 1 1/2"	003617F													1	1	1	1	1	1	1	
	Pressure Regulator Pro 2 1/2"	600078													1	1						
	Pressure Regulator Pro 2"	003604F																	1	1	1	
	Gas Valve Body Pro 1"	014014F																				
	Gas Valve Body Pro 1 1/4"	014015F						1	1													
	Gas Valve Body Nat 1 1/2"	600452																				
	Gas Valve Body Pro 2"	600453						1	1	1	1	1					1	1	1	1	1	
	Comb. Gas Valve Pro 1"	003573F			1	1																
	Comb. Gas Valve Nat 1 1/2"	600633			1	1	1	1														
	Comb. Gas Valve Pro 1"	N/A																				
	Actuator, Modulation	600449																				
	Actuator, On-Off	011908F						1	1	1	1	1	1									
	Gas Pressure Switch (high)	007188F						1	1	1	1	1	1					1	1	1	1	
	Pilot Gas Valve	600562			1	1	1	1	1	1	1	1	1									
	Comb. Gas Valve 2-Stage Nat 1 1/4"	600656																				
	Comb. Gas Valve 2-Stage Pro 1"	003607F													1							
	Comb. Gas Valve 2-Stage Nat 1 1/2"	600850																				
	Comb. Gas Valve 2-Stage Pro 1 1/4"	003608F													1	1	1					
	Actuator, 2 Stage	600458																				
*	Gas Pressure Switch (low)	007187F		1	1	1	1	1	1	1	1	1	1		1	1	1	1	1	1	1	
	Gas Pressure Switch (high)	007188F		1	1	1	1	1	1	1	1	1	1		1	1	1	1	1	1	1	
*	Lube/Cock Valve 2"	600327			2	2	2	2	2	2	2	2	2		2	2	2	2	2	2	2	
*	Lube/Cock Valve 2 1/2"	600328																				
*	Gas Vent Valve 1"	011914F			1	1	1	1	1	1	1	1	1		1	1	1	1	1	1	1	
*	Gas Vent Valve 1 1/4"	600548																		1	1	



www.raypak.com